


Resistance Temperature Detectors


Model No. SS-5030 Series

Weather Proof Head Type


Model No. | SS-5031W
(Metal Protection Tube)




Model No. | SS-5031W-2
(Metal Protection Tube)




Model No. | SS-5032W
(Metal Protection Tube)




Model No. | SS-5032W-1
(Metal Protection Tube)




Model No. | SS-5032W-2
(Metal Protection Tube)




Model No. | SS-5032W-3
(Metal Protection Tube)




Model No. | SS-5032W-4
(Metal Protection Tube)




Model No. | SS-5032W-6
(Metal Protection Tube)




Model No. | SS-5033W
(Metal Protection Tube)




Model No. | SS-5034W-1
(Metal Protection Tube)



Model No. | SS-5034W-2
(Metal Protection Tube)




Model No. | SS-5035W
(Metal Protection Tube)




Pressure Gauge
Differential Pressure Gauge & Switch
Accessories of Pressure Gauge
Thermometer & Thermometer Switch
Thermocouple & R.T.D.
Thermowell
Transmitter
Indicator etc.
Technical data

Weather Proof Head Type


Model No. | SS-5035W-1
(Metal Protection Tube)




Model No. | SS-5036W
(Metal Protection Tube)




Model No. | SS-5036W-2
(Metal Protection Tube)




Model No. | SS-5036W-3
(Metal Protection Tube)




Model No. | SS-5037W
(Metal Protection Tube)




Model No. | SS-5039W
(Metal Protection Tube)



Model No. | SS-5039W-1
(Metal Protection Tube)



Model No. | SS-5039W-2
(Metal Protection Tube)



Pressure Gauge

Differential Pressure Gauge & Switch

Accessories of Pressure Gauge

Thermometer & Thermometer Switch

Thermocouple & R.T.D

Thermowell

Transmitter

Indicator etc.


Technical data

Resistance Temperature Detectors


Model No. SS-5030 Series

Explosion Proof Head Type (Ex d IIC T6)


Model No. | SS-5031E
(Metal Protection Tube)




Model No. | SS-5031E-2
(Metal Protection Tube)




Model No. | SS-5032E
(Metal Protection Tube)




Model No. | SS-5032E-1
(Metal Protection Tube)




Model No. | SS-5032E-2
(Metal Protection Tube)




Model No. | SS-5032E-3
(Metal Protection Tube)




Model No. | SS-5032E-4
(Metal Protection Tube)




Model No. | SS-5032E-6
(Metal Protection Tube)




Model No. | SS-5033E
(Metal Protection Tube)




Model No. | SS-5034E-1
(Metal Protection Tube)



Model No. | SS-5034E-2
(Metal Protection Tube)




Model No. | SS-5035E
(Metal Protection Tube)




Pressure Gauge
Differential Pressure Gauge & Switch
Accessories of Pressure Gauge
Thermometer & Thermometer Switch
Thermocouple & R.T.D.
Thermowell
Transmitter
Indicator etc.
Technical data

Explosion Proof Head Type (Ex d IIC T6)


Model No. | SS-5035E-1
(Metal Protection Tube)




Model No. | SS-5036E
(Metal Protection Tube)




Model No. | SS-5036E-2
(Metal Protection Tube)




Model No. | SS-5036E-3
(Metal Protection Tube)




Model No. | SS-5037E
(Metal Protection Tube)




Model No. | SS-5039E
(Metal Protection Tube)



Model No. | SS-5039E-1
(Metal Protection Tube)



Model No. | SS-5039E-2
(Metal Protection Tube)



Pressure Gauge

Differential Pressure Gauge & Switch

Accessories of Pressure Gauge

Thermometer & Thermometer Switch

Thermocouple & R.T.D

Thermowell

Transmitter

Indicator etc.


Technical data

Resistance Temperature Detectors


Model No. SS-5030 Series

General Purpose Head Type


Model No. | SS-5031S
(Metal Protection Tube)




Model No. | SS-5031S-2
(Metal Protection Tube)




Model No. | SS-5032S
(Metal Protection Tube)




Model No. | SS-5032S-1
(Metal Protection Tube)




Model No. | SS-5032S-2
(Metal Protection Tube)




Model No. | SS-5032S-3
(Metal Protection Tube)




Model No. | SS-5032S-4
(Metal Protection Tube)




Model No. | SS-5032S-6
(Metal Protection Tube)




Model No. | SS-5033S
(Metal Protection Tube)




Model No. | SS-5034S-1
(Metal Protection Tube)



Model No. | SS-5034S-2
(Metal Protection Tube)




Model No. | SS-5035S
(Metal Protection Tube)




Pressure Gauge
Differential Pressure Gauge & Switch
Accessories of Pressure Gauge
Thermometer & Thermometer Switch
Thermocouple & R.T.D.
Thermowell
Transmitter
Indicator etc.
Technical data

General Purpose Head Type


Model No. | SS-5035S-1
(Metal Protection Tube)




Model No. | SS-5036S
(Metal Protection Tube)




Model No. | SS-5036S-2
(Metal Protection Tube)




Model No. | SS-5036S-3
(Metal Protection Tube)




Model No. | SS-5037S
(Metal Protection Tube)




Model No. | SS-5039S
(Metal Protection Tube)



Model No. | SS-5039S-1
(Metal Protection Tube)



Model No. | SS-5039S-2
(Metal Protection Tube)



Pressure Gauge

Differential Pressure Gauge & Switch

Accessories of Pressure Gauge

Thermometer & Thermometer Switch

Thermocouple & R.T.D

Thermowell

Transmitter

Indicator etc.

Technical data